

Tips & Tricks

A Couple of Building Hints

How many times have you used the household iron and been jumped on for leaving sticky stuff on it? Have you used iron-on film and had the color pigment stick to the iron and bleed to another section leaving streaks and marks on the second color (red on white, for instance)?

Solution: Heat the iron, put some salt on any sheet of paper and rub the iron over the salt. PRESTO! Iron face back in pristine condition.

—*From the Tingalpa Transmitter in Australia*

When drilling a hole in balsa, the wood has a tendency to splinter out and make a nasty mess where the drill bit exits. Drip a few drops of thin Hot Stuff around the exit area of the drill bit and let it cure. You can now drill a hole and the wood will hold together much better. It may still splinter out some, but not nearly as much. This method also works great when drilling wing hold-down holes on built-up wings.

—*From the Windy Flyer newsletter, Downers Grove, Illinois*